
# 30. Air Mix Door Actuator

# A: REMOVAL


### 1. LH

- 1) Remove the knee airbag module. <Ref. to AB-34, REMOVAL, Knee Airbag Module.>
- 2) Remove the motor actuator mix.
  - (1) Disconnect the connector, and remove the rod from the rod clamp.
  - (2) Remove the screws and detach the motor actuator mix.



### 2. RH

- 1) Remove the glove box. <Ref. to EI-78, REMOVAL, Glove Box.>
- 2) Remove the motor actuator mix.
  - (1) Disconnect the connector, and remove the rod from the rod clamp.
  - (2) Remove the screws and detach the motor actuator mix.



## **B: INSTALLATION**

Install each part in the reverse order of removal.

# C: INSPECTION

## 1. CHECK LINK

- 1) Visually check the operation range of the link, and remove the foreign material if any.
- 2) Operate the temperature control dial to check that the link operates normally.
- 3) If it does not operate normally as the result of inspection, check the motor actuator mix.

## 2. CHECK ACTUATOR

## **UNIT INSPECTION**

### PREPARATION TOOL:

#### Circuit tester

1) Check the resistance between actuator terminals.

Terminal No.	Inspection conditions	Standard	Connector sketch	
3 — 1			ţ	
3 — 2				
3 — 5				
3 — 6	Always	80 — 100 Ω		$\Omega$
				AC-02839

2) Replace the motor - actuator mix if it is found defective as a result of inspection.